

Advanced Sensing Techniques

Lecture Material 3




Few references:

1. Fundamentals of Microfabrication by Marc Madou
2. Micro and Smart systems: G . K. Ananthasuresh et al.
3. Couple of Internet sources for Image illustration

Dr. B. Mukherjee & Prof. S. Sen

Etching

- Etch: removal of material from wafer (e.g. removal silicon dioxide)
- Isotropic vs. Anisotropic
 - Isotropic– etch rate is same in all directions
 - Anisotropic– etch rate is orientation dependent



Wet Etching


- Sample is kept in etchant solution for specified amount of time
- Sample is removed from solution
- Sample is rinsed in deionized water and dried

Example Mechanism: e.g. Etchant HF, HNO3 to remove Si

hole injection: $\text{HNO}_3 + \text{H}_2\text{O} + \text{HNO}_2 \rightarrow 2\text{HNO}_2 + 2\text{OH}^-$

oxidation: $\text{Si}^{4+} + 4\text{OH}^- \rightarrow \text{SiO}_2 + \text{H}_2$


oxide removal: $\text{SiO}_2 + 6\text{HF} \rightarrow \text{H}_2\text{SiF}_6$





Dry Etching

- Etchant is in gas form
- Physical & Chemical mechanism:
 - Removal based on impact, momentum transfer and chemical reaction;
 - Good material selectivity, directional control and high etch rate



Example: Etchant Cl_2 , CCl_2 , F_2 to remove Si



Wire Bonding and Packaging






Packaging of MEMS at SCL, Chandigarh




PGA: Pin Grid Array (100 pin here)

Example: PIEZORESISTIVE SILICON ACCELEROMETER

Microphotograph of fabricated accelerometer



Packaged accelerometer device



Accelerometer performance tested at ADE, Bangalore

	Z-axis	X axis	Y axis
Sensitivity ($\mu\text{V/g}$):	570	30	26
Linearity (% of FS):	0.19	1.5	0.63



Testing

Sensing and Actuation Methods

- ❖ Electrostatic (Preferable)
- ❖ Piezoelectric
- ❖ Thermal
- ❖ Magnetic etc.



➤ Advantages of ES method:

- ✓ Less resource requirement
- ✓ CMOS integration compatibility
- ✓ Large force generation
- ✓ Scalability etc.



Popular Testing Equipment

Micro System Analyzer



Cycle

